

Brand: Alfa Laval



Model	Plate	Gasket
A10B	✓	✓
A15	✗	✓
A15B	✓	✓
A15BW	✗	✓
A20B	✓	✓
AC600	✓	✓
AC800	✗	✓
AK20	✓	✓
AM10	✓	✓
AM20	✓	✓
AM20B	✓	✓
AM20S	✗	✓
AX30B	✓	✓
CLIP3	✗	✓
CLIP6	✓	✓
CLIP8	✓	✓
CLIP10	✓	✓
EC350	✓	✓
EC500	✓	✓
M3	✓	✓
M3 Double-wall	✓	✓
M6B	✓	✓
M6B Double-wall	✓	✓
M6M	✓	✓
M6M Double-wall	✓	✓
M6MW Semi-welded	✓	✓
M10B	✓	✓
M10B Double-wall	✓	✓
M10BW Semi-welded	✓	✓
M10M	✓	✓
M10M Double-wall	✓	✓
M10MX	✓	✓
M15B	✓	✓
M15B Double-wall	✓	✓
M15M	✓	✓
M15M Double-wall	✓	✓
M20MW Semi-welded	✓	✓
M30	✓	✓
MA30M	✓	✓
MA30S	✓	✓

Model	Plate	Gasket
MA30W Semi-welded	✓	✓
MK15BW Semi-welded	✓	✓
MX25B	✓	✓
MX25M	✓	✓
P2	✓	✓
P14	✗	✓
P16	✓	✓
P22	✓	✓
P25	✗	✓
P26	✓	✓
P28	✗	✓
P30	✗	✓
P31	✗	✓
P32	✗	✗
P36	✓	✓
P105	✗	✗
P190	✗	✗
T2B	✗	✓
T4	✓	✓
T5B	✗	✓
T5M	✗	✓
T8B	✗	✓
T8M	✗	✓
T20B	✓	✓
T20BW	✗	✓
T20M/ (M20M)	✓	✓
T20P	✓	✓
T35P	✓	✓
T45M	✗	✓
T50M	✗	✓
TL3B	✗	✓
TL3P	✗	✓
TL6B	✓	✓
TL10B	✓	✓
TL10B Double-wall	✓	✓
TL10P	✓	✓
TL15B	✓	✓
TL35B	✓	✓
TL35B	✓	✓
TS6L	✗	✗
TS6M	✓	✓
TS20M	✓	✓
TS35P	✓	✓
TS50M	✗	✓
Widegap200S	✓	✓
Widegap350S	✓	✓

Brand: Sondex



Model	Plate	Gasket
S4A	✓	✓
S7A	✓	✓
S8A	✓	✓
S8	✓	✓
S9A	✓	✓
S14A	✓	✓
S14	✗	✓
S15A	✓	✓
S15	✗	✓
S16B	✗	✓
S17	✓	✓
S18	✗	✓
S19A	✓	✓
S19	✗	✓
S20A	✓	✓
S21A	✓	✓
S21	✓	✓
S22	✓	✓
S30	✗	✓
S31A	✓	✓
S35	✗	✓
S37	✓	✓
S38	✗	✓
S41A	✓	✓
S41	✓	✓
S42A	✓	✓
S42	✓	✓
S43A	✓	✓
S43	✓	✓
S44A	✗	✓
S47	✓	✓
S47A	✓	✓
S47B	✗	✓
S50	✗	✓
S58	✗	✓
S62	✓	✓
S63	✓	✓
S64	✓	✓
S65	✓	✓

Model	Plate	Gasket
S65A	✗	✓
S81	✓	✓
S86	✓	✓
S86B	✗	✓
S100	✓	✓
S110	✓	✓
S113	✓	✓
S120	✗	✓
S121	✓	✓
S130	✓	✓
S188	✓	✓
S251	✓	✓
SW40	✗	✓
SF25A	✗	✓
SF53	✗	✓
SF123	✓	✓
SF160	✓	✓
SFD13	✓	✓
SFD23	✓	✓

Brand: APV



Model	Plate	Gasket
A055	✓	✓
A085	✓	✓
A145	✓	✓
B063	✓	✓
B134	✓	✓
C134	✗	✓
CS235	✗	✓
CS500	✗	✓
H10	✗	✓
H12	✓	✓
H17	✓	✓
H20	✓	✓
H30	✗	✓
H35	✓	✓
HX	✗	✓
J060	✓	✓
J092	✓	✓
J107	✓	✓
J185	✓	✓
K34	✓	✓
K55	✓	✓
K71	✓	✓
L039	✗	✓
L080	✗	✓
M60	✓	✓
M92	✓	✓
M107	✓	✓
M185	✓	✓
N25	✓	✓
N35	✓	✓
N50	✓	✓
O034	✗	✓
O050	✗	✓
P105	✓	✓
P190	✓	✓
Q030D	✓	✓
Q030E	✓	✓
Q055D	✓	✓
Q055E	✓	✓

Model	Plate	Gasket
Q080D	✗	✓
Q080E	✓	✓
R5	✓	✓
R8	✓	✓
R10	✓	✓
R14	✓	✓
R145	✓	✓
SR1	✓	✓
SR2	✓	✓
SR3	✓	✓
SR6AA	✗	✓
SR6AG	✓	✓
SR6GH	✗	✓
SR6GL	✓	✓
SR6GN	✗	✓
SR14AH	✗	✓
SR23AO	✗	✓
SR23VO	✗	✓
SR95	✓	✓
T4	✓	✓
TR9AL	✓	✓
TR9AV	✓	✓
TR9GL	✓	✓
TR9GN	✓	✓
Z155	✗	✓

Brand: Tranter



Model	Plate	Gasket
SX415	x	✓

* UFX (old) = GXD(new)

Model	Plate	Gasket
GC8	✓	✓
GC09	✓	✓
GC16	✓	✓
GC26	✓	✓
GC30	x	✓
GC51	✓	✓
GC60	✓	✓
GCD044	x	✓
GCD054	✓	✓
GF57	✓	✓
GF97	✓	✓
GF187	✓	✓
GL13	✓	✓
GL205	✓	✓
GL230	✓	✓
GL330	✓	✓
GL85	✓	✓
GX07	x	✓
GX12	✓	✓
GX18	✓	✓
GX26	✓	✓
GX42	✓	✓
GX51	✓	✓
GX60	✓	✓
GX64	✓	✓
GX85	✓	✓
GX91	✓	✓
GX100	✓	✓
GX118	✓	✓
GX140	✓	✓
GX145	✓	✓
GX180	✓	✓
GX205	✓	✓
GX265	✓	✓
O6T	✓	✓
S3	x	✓
S8	x	✓
UXP-200	✓	✓
UXP400	✓	✓

Brand: Schmidt



Model	Plate	Gasket
SIGMA 7	✓	✓
SIGMA 9	✓	✓
SIGMA 13	✓	✓
SIGMA 22	✓	✗
SIGMA 25	✓	✓
SIGMA 26	✓	✓
SIGMA 27	✓	✓
SIGMA 35	✓	✓
SIGMA 35X	✓	✓
SIGMA 36	✓	✓
SIGMA 37	✓	✓
SIGMA 55	✓	✓
SIGMA 55X	✓	✓
SIGMA 56	✓	✓
SIGMA 66	✓	✓
SIGMA 76	✗	✓
SIGMA 96	✗	✓
SIGMA M136	✓	✓
SIGMA 150	✓	✓
SIGMA 156	✓	✓
SIGMA K108	✓	✓
SIGMA K138	✓	✓
SIGMA K185	✓	✓
SIGMA STAR 45	✗	✓
SIGMA STAR 90	✗	✓
SIGMA STAR 150	✗	✓
SIGMA X13	✓	✓
SIGMA X19	✓	✓
SIGMA X29	✓	✓
SIGMA X49	✓	✓

Brand: HISAKA



Model	Plate	Gasket
LX015A	✓	✓
LX015B	✓	✓
LX016A	✗	✓
LX025A	✓	✓
LX025B	✓	✓
LX026B	✓	✓
LX095A	✗	✓
LX10A	✓	✗
LX20	✓	✓
LX50A	✓	✓
LX115A	✓	✓
LX125B	✓	✗
LX126A	✓	✗
LX195A	✓	✗
LX195B	✓	✗
LX216	✗	✓
LX226	✓	✓
LX298	✗	✓
LX315A	✓	✓
LX315B	✗	✓
LX316A	✗	✓
LX325A	✓	✓
LX325B	✗	✓
LX395	✓	✓
LX515A	✓	✓
LX525A	✓	✓
LX526	✓	✓
LX526A	✓	✓
LX526B	✓	✓
LX595A	✓	✓
LX595B	✗	✓
RX115A	✗	✓
RX135A	✗	✓
RX135B	✗	✓
RX136A	✗	✓
RX145A	✓	✓
RX185A	✗	✓
RX185B	✗	✓
RX186A	✗	✓

Model	Plate	Gasket
RX315A	✗	✓
RX315B	✓	✓
RX316A	✗	✓
RX325A	✓	✓
RX352A	✗	✓
RX395A	✗	✓
RX395B	✓	✓
RX595B	✗	✓
RX725	✓	✗
RX795	✗	✓
UX005	✓	✓
UX005A	✓	✓
UX01	✓	✓
UX05	✓	✓
UX016	✓	✓
UX016A	✓	✓
UX076	✗	✓
UX10	✗	✓
UX20	✓	✓
UX20A	✓	✓
UX30A	✗	✓
UX40	✓	✓
UX80	✓	✓
UX90	✓	✓
UX100	✗	✓
UX110	✗	✓
UX115	✗	✓
UX116	✗	✗
UX125	✗	✓
UX195A	✗	✓
UX195B	✗	✓
UX216	✗	✓
UX218	✗	✓
UX296	✗	✓
UX315A	✗	✓
UX325A	✗	✓
UX326B	✗	✓
UX395B	✗	✓
UX496	✓	✓
UX895	✓	✓
UX925	✓	✓

Brand: Vicarb


Model	Plate	Gasket
V2	✓	✓
V4	✓	✓
V8	✓	✓
V13	✓	✓
V20	✓	✓
V28	✓	✓
V45	✓	✓
V60	✓	✓
V65	✓	✓
V85	✓	✓
V100	✓	✓
V110	✓	✓
V130	✓	✓
V170	✓	✓
V280	✓	✓

Brand: Fisher


Model	Plate	Gasket
E5	×	✓
E6	×	✓
E8	×	✓
E18	×	✓
E40	×	✓
E51	×	✓
E61	×	✓
E82	×	×
EX15	×	✓

Brand: Thermowave


Model	Plate	Gasket
TL50PP	✓	✓
TL90PP	✓	✓
TL90SS	✓	✓
TL150PP	✓	✓
TL150SS	✓	✓
TL200PP	✓	✓
TL200SS	✓	✓
TL250PP	✓	✓
TL250SS	✓	✓
TL400PP	✓	✓
TL400SS	✓	✓
TL500PP	✓	✓
TL500SS	✓	✓
TL650PP	✓	✓
TL650SS	✓	✓
TL850PP	✓	✓
TL850SS	✓	✓

Brand: DHP


Model	Plate	Gasket
DX17	✓	✓
DX22	✓	✓
DX30L	✓	✓
DX30S	✓	✓
DX55	×	✓
DX143	✓	✓
DX146	✓	✓

Brand: Funke



Model	Plate	Gasket
FP04	✓	✓
FP05	✓	✓
FP08	✓	✓
FP09	✓	✓
FP10	✓	✓
FP14	✓	✓
FP16	✓	✓
FP19	✓	✓
FP20	✓	✓
FP22	✓	✓
FP31	✓	✓
FP40	✓	✓
FP41	✓	✓
FP42	✓	✓
FP50	✓	✓
FP60	✓	✓
FP62	✓	✓
FP70	✓	✓
FP71	✗	✓
FP80	✓	✓
FP81	✓	✓
FP82	✗	✗
FP100	✓	✓
FP112	✓	✓
FP120	✓	✓
FP130	✓	✓
FP160	✓	✓
FP200	✗	✓
FP205	✓	✓
FP250	✗	✓
FP405	✓	✓

Brand: LHE



Model	Plate	Gasket
HT061	✗	✓
HT062	✗	✓
HT064	✓	✓
HT101	✓	✓
HT102	✓	✓
HT103	✓	✓
HT104	✓	✓
HT150	✓	✓
HT151	✓	✓
HT152	✗	✓
HT156	✗	✓
HT201	✗	✓
HT231	✓	✓
HT232	✗	✓
HT232H	✗	✓
HT233	✗	✓
HT351	✗	✓
HT50	✗	✓

* LH= HT